



Basic instructions for using our Fiddes & Sons Supreme Wax Polish.

1. After opening the can, you may see liquid on top of the wax. This is normal. Stir it in, or you may melt the wax to a liquid. Using the wax in liquid form gives you better penetration into your finish. You will also use less product this way. Remember.....LESS is better. If you prefer a harder consistency, simply refrigerate the wax for a few minutes.
2. Apply the wax with a brush in paste or liquid form, whichever you prefer.
3. Only cover a small area at a time. You **MUST** wipe off excess wax with a soft cloth and let dry. Wax will dry in approximately 3 minutes.
4. Apply a second coat if you need more protection or color.
5. Once dry, buff with a soft clean cloth or a buffing brush.

**\*\*Please Note\*\***

- If you notice finger prints in your wax finish, you are applying more than is necessary.
- If your finished wax color is too dark, you may lighten it by rubbing in some clear wax with a cloth.
- Using clear wax as an undercoat will give you more control of your dark wax finish.

Give your project 24 hours for your wax to cure before using.