



Basic instructions for using Country Paint Casting Products

Texture Casting can be used with our templates for a raised design on your furniture. It can also be used for a textured finish on picture frames, art and craft, or many other projects. You may also repair wood with Texture Casting. It can be tinted with paint or stain, and is very durable when dry.

Secure your template in place with tape or by simply holding it.

Use your Country Paint Casting Knife to spread the texture casting into the template openings. For small intricate designs, add a few drops of water to the Texture Casting so it will release through the template easier.

Gently remove the template by lifting straight up.

Let completely dry.

This process can be repeated on top of the first casting once dry for a more raised design.

Clean your template and knife gently with soap and water right away.

Sand your design for a smoother, more uniform finish.

Paint, stain or wax (you may pre tint your Texture Casting before using).

Sand again for a distressed finish.