



Basic instructions for using Country Paint Simple Glaze

Simple Glaze is used for achieving a distressed or vintage look. Apply directly over your Chalked Country Paint with a brush or rag. Remove immediately with a clean rag, leaving in the cracks and crevices. You can apply more glaze if needed to achieve different effects.

Clean brushes with soap and water.

Country Paint Simple Glaze is available in clear, white, and black. Clear Simple Glaze must be tinted before using. Use the formula below for mixing.

Fast dry results, mix 2 parts glaze to 1 part Chalked Country Paint.

Slower dry results, mix 3 parts glaze to 1 part Chalked Country Paint.